

INSTRUCTIONS BM1508

REV# 2 12-19-16






FOR ASSEMBLY

2/4

INSTRUCTIONS BM1508


STEP 1 Seat Assembly

- Locatethe bench ends (A) and the seat frame (B)
- Insert (2) button head screws (F) with washers (H) thru the bench ends (A) and into the tab on the seat frame (B)
- Secure the bench end to the seat frame with washers and (H) and hex nuts (G)
- Repeat for the other bench end



STEP 2 Backrest Assembly

- Hold the backrest assembly (C) in between the bench ends (A)
- The slats are flush to the front side of the assembly
- Align the holes in the bench ends (A) with the holes in backrest assembly (C)
- Insert (2) button head screws (F) with washers (H) through the holes and secure with washers (H) and hex nuts (G)
- Repeat for the other side



ASSEMBLY

INSTRUCTIONS **BM1508**

Step 3 Attach the Seat and Armrests

Lay the seat slats (D) across the seat frame (B)
Each seat slat has pre-marked location holes in them
From the bottom align the holes in the seat frame (B) with the location holes in the seat slats (D) See Detail 1
Secure the seat slats to the seat frame with #10 x .75" pan head

screws (I)

Align the holes in the bench ends (A) with the location holes in the armrests (E)

Secure the armrests to the bench ends with #10 x .75" pan head screws (I) See Detail 2

> DETAIL 2 DETAIL 1 **DETAIL 2 ATTACH** 4/4 **SEAT AND**

> > **ARMS**

